



INSTRUCTION MANUAL

SAW HORSE

(Max. Weight Capacity 100kg)

Model No: THBSH -- Product No: 193833001

ASSEMBLY REQUIRED

SAVE THESE INSTRUCTIONS

SPARES & SUPPORT: 01793 333212

Please read & understand this manual, paying particular attention to the safety instructions, before use.

The manufacturer reserves the right to change the product specification and livery according to continued product improvements.

Images used are for illustration purposes only

CONTENTS

SPECIFICATIONS
IMPORTANT INFORMATION
GENERAL SAFETY INSTRUCTIONS
ASSEMBLY
OPERATION
CLEANING
STORAGE & TRANSPORT
WARRANTY

Assembly Is Required

This product requires assembly before use. See the “Assembly” section for instructions. Please check that all parts required for the assembly of this spreader are included. If for any reason you believe a part for the assembly is missing or damaged, please contact us.

If you require any assistance with regards to the contents or operation of your machine, please contact us:

TEL: 01793 333212

EMAIL: customerservice@handydistribution.co.uk
(MON – FRI 8.00AM TO 5.30PM EXCL. BANK HOLIDAYS)

SPECIFICATION

The manufacturer reserves the right to change the product specification and livery according to continued product improvements.

Model Number	THBSH
Product Number	193833001
Working Dimensions	H-795mm x W-800mm x L-815mm
Max. Log Diameter	300mm
Max. Weight Capacity	100kg
Material	Galvanised Steel
Weight	G.W 8.5kg - N.W 8kg

IMPORTANT INFORMATION

INTENDED USE

The device is intended for to securely hold logs & wood to assist with the cutting, by chainsaw or handsaw.








This product is not intended for commercial use.

Generally acknowledged accident prevention regulations and enclosed safety instructions must be observed.

Only perform work described in these instructions for use. Any other use is incorrect. The manufacturer will not assume responsibility for damage resulting from such use.

GENERAL SAFETY INSTRUCTIONS

It is important that you read and understand the owner's manual and labels affixed to the machine. Learn its application and limitations as well as the specific potential hazards. Retain these instructions for future reference. The operator is responsible for following the warnings & instructions in this manual and on the product.

	<p>Read & understand operator's manual before using the machine. Failure to follow instructions could result in death or serious injury.</p>		<p>Risk of Slicing. Keep hands out of the way of all moving parts.</p>
	<p>Use safety equipment. Always wear eye protection. Safety equipment such as a dust mask, non-skid safety shoes, hard hat, and heavy duty work gloves used for appropriate conditions will reduce personal injuries.</p>		<p>Safety alert symbol. Used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury.</p>
	<p>Indicates an imminently hazardous situation which, if not avoided, will result in serious injury.</p>		<p>Indicates a potentially hazardous situation which, if not avoided, could result in serious injury</p>
	<p>Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.</p>	<p>CAUTION</p>	<p>Used without the safety alert symbol indicates a potentially hazardous situation which, if not avoided, may result in property damage.</p>

STAY ALERT

Do not operate the machine while under the influence of drugs, alcohol, or any medication that could affect your ability to use it properly. Do not use this machine when you are tired or distracted from the job at hand. Be aware of what you are doing at all times. Use common sense.

AVOID DANGEROUS CONDITIONS

Make sure there is adequate surrounding workspace. Cluttered areas invite injuries. Keep your work area clean with sufficient light. Keep the area around the machine clear of obstructions, grease, oil, rubbish and other debris which could cause persons to fall onto moving parts.

INSPECT YOUR MACHINE

Check all bolts, nuts, and screws for tightness before each use, especially those securing guards and drive mechanisms. Vibration during use, may cause these to loosen.

Form a habit of checking to see that all other tools/equipment are removed from the working area before using.

Replace damaged, missing or failed parts before using it.

Warning labels carry important information. Replace any missing or damaged warning labels.

DRESS PROPERLY

Do not wear loose clothing, gloves, scarfs, neckties or jewelry (rings, wrist watches), which can be caught in moving parts. Protective electrically non-conductive gloves and non-skid heavy duty footwear are highly recommended when working. Wear protective hair covering to contain long hair, preventing it from getting caught in machinery.

KEEP BYSTANDERS AND CHILDREN AWAY

Keep unauthorised persons away from the machine. If approached, stop the machine immediately. Do not allow children to handle or climb on the machine.

DO NOT OVERREACH

Keep proper footing and balance at all times when using the machine. Never stand on the machine. Serious injury could occur if the machine is tipped or if the moving parts are unintentionally contacted. Do not store anything above or near the machine, where anyone might stand on the machine to reach them.

AVOID INJURY FROM UNEXPECTED ACCIDENT

Keep hands & feet out of the way of all moving parts. Do not place any part of your body or any tool e.g. in the machine during operation.

DO NOT FORCE TOOL

Always work within the rated capacity. Do not use the machine for a purpose for which it was not intended.

NEVER LEAVE MACHINE UNATTENDED

Do not leave the machine unattended until it has come to a complete stop.

MAINTAIN YOUR PRODUCT WITH CARE

Clean the machine immediately after use. Keep the machine clean to ensure it operates to its full & safest performance. When maintaining this machine, only the manufacturer's original replacement parts should be used. The use of non-original manufacturer parts may invalidate your warranty.

PROTECT THE ENVIRONMENT

Take left over materials to an authorised collection point or follow the stipulations in the country where the mixer is used. Do not discharge into drains, soil or water.

STORE IDLE EQUIPMENT

When not in use, the machine should be stored in a dry location. Keep the machine away from children and others not qualified to use it.


ASSEMBLY



DANGER

It is recommended that safety gloves are used during the assembly of this item.

HARDWARE INCLUDED



The package will also include, 6x serrated legs, 2x 80cm cross struts, 2x 84cm diagonal cross struts.

IF YOU BELIEVE A COMPONENT IS MISSING OR DAMAGED, PLEASE CONTACT US FOR ASSISTANCE.

CONSTRUCTION

You will require 2x 10mm and 2x 14mm spanners to assemble this product (Not Included)

The Handy Saw Horse is supplied with Nylock Nuts. They are designed with a nylon collar, with a slightly smaller diameter to the bolt. The insert deforms elastically over the threads of the screw, but threads are not cut into the nylon. The nylon insert, locks the nut by applying a compressive force against the bolt. Please ensure that you completely tighten the construction.

Firstly, pair the six legs using M8x16 bolt, two M8 washers and a M8 lock nut into the round hole, just below the serrated edges. The serrated edges should be facing one another.



Then fit a M6x12 Bolt with two M6 washers and a M6 lock nut into the curved slot on the paired leg assemblies.



When secured, ensure that the legs can be opened and closed. For assembly, keep closed.

You have four cross struts, 2x 80cm and 2x 84cm in length. The 80cm cross struts run across the bottom of the horse, whilst the two 84cm cross struts will run diagonal.



Secure the shorter cross strut (80cm) to the left and middle leg assembly bottom fixing hole, using M6x12 bolt, M6 washer and M6 nut.



Attach the longer diagonal cross strut (84cm) and the smaller (80cm) cross strut to the right leg assembly, using a M6x25 bolt & M6 nut. The metal on the struts will splay outwards with the tightening of the nut & bolt as imaged.



Align the fixing holes of the diagonal cross strut to the middle & left leg assembly. Attach to the left leg assembly, using the 4th hole from the floor, with a M6x12 bolt, M6 washer and M6 nut.



Secure to the middle leg, using the third hole from the floor, securing with M6x12 bolt and M6 nut.




Turn the stand over and follow the same procedure.

Attach the diagonal strut in the opposite direction to the previous side. The diagonal strut should be fitted to the second hole of the middle leg on this occasion (see image).



The finished product, should have a large and small section, to allow you to position different length logs for cutting. One section should measure 33cm and the larger section 39.5cm.



SAFETY WARNING

The correct assembly of this item is essential, for both your personal safety and to guarantee the product satisfaction. We cannot be held responsible for any accident resulting from improper or irresponsible use of this product.

It is essential that this item is inspected before use and maintained in accordance with these instructions.

- Ensure the ground is level
- Open the legs to their widest (26cm) and the sliding lock bolt tightened
- Always make sure that all bolts are tight and secure before you attempt to use this item.

OPERATION



DANGER

The product must only be put into operation if no defects are found. It is crucial that any defective parts are replaced before the product is used again.

The saw horse is designed for wood lengths of 1.8 metres (max.), diameter 25cm (max.), with a maximum permissible load of 100kg.

- Check the safety equipment and the safe condition of the product:
- Check all parts to make sure that they fit tightly.
- Check whether there are any visible defects: broken parts, cracks, etc.



WARNING

Never use the product on slopes. Always work on level ground, ensuring you have a stable footing. Use common sense when cutting wood with a hand saw, petrol, cordless or electric chainsaw.

CLEANING

- Careful handling and regular cleaning ensure that the device will remain functional for a long time.
- Brush off coarse dirt.
- Wipe down the device with a slightly damp cloth.

STORAGE & TRANSPORT

STORAGE



WARNING

Make sure that unauthorised persons do not have access to the device!

- Store the machine in a dry place
- Store away from direct sunlight
- Do not store anything above or near the machine, where anyone might stand on the machine to reach them.
- Keep the machine away from children and others not qualified to use it.

TRANSPORT

- Secure the device against slipping.
- When shipping, use the original packaging if possible.

GJ HANDY & CO LTD USER WARRANTY POLICY

Users Statement of Warranty

Each new machine is warranted against defective material or assembly of material under normal usage. The warranty applies to the original purchaser and covers faulty parts and the labour involved in replacing and repairing those parts, which are of original manufacture.

Period of Warranty

All Webb & Webb Pro machines plus Sanli engines.

- a) 2 years from the original date of sale to the first domestic user.
- b) 90 days from the original date of sale to the professional/commercial user.
- c) 90 days from the original date of sale when used for hire.
- d) A reduced warranty period of 90 days applies to those items which are subject to normal wear and tear (e.g. but not limited to wheels, tyres, cutter bars, cylinders, blades, belts, cables, grass bags, spark plugs).
- e) Engines as per the manufacturer's warranty statement which will be supplied with the machine.
- f) 90 days from the original date of purchase for Replacement Spare Parts (unless normal wear & tear component, which are covered for 30 days).
- g) All machines' must be serviced within the first 12 months from the original date of purchase to comply with the warranty, failure to do so will invalidate the 2nd year of the warranty.

All Handy, Mowerland and Q-Garden products.

- a) 1 year from the original date of sale to the first domestic user.
- b) 90 days from the original date of sale to the professional/commercial user.
- c) 90 days from the original date of sale when used for hire.
- d) A reduced warranty period of 90 days applies to those items which are subject to normal wear and tear (e.g. but not limited to wheels, tyres, cutter bars, cylinders, bottom blades, belts, cables, collection bags, spark plugs).
- e) Engines as per the manufacturer's warranty statement which will be supplied with the machine.
- f) 90 days from the original date of purchase for Replacement Spare Parts (unless normal wear & tear component, which are covered for 30 days).

All warranty repairs must be undertaken by an authorised service dealer. These dealers have been accredited by GJ Handy & Co Ltd and agree to only use genuine parts and follow our repair procedures.

VERSION 4 – (10/16)

23/03/2017

GJ HANDY & CO LTD USER WARRANTY POLICY

Not covered by this warranty

- a) The warranty policy does not cover any depreciation or damages caused by ordinary wear, rusting or corrosion, lack of correct maintenance or operation, misuse, abuse, lack of transportation or accident.
- b) The warranty policy does not cover any costs necessary for the standard periodic maintenance services instructed by the operator's manual, or service parts replacement which would include oil, filters, tyres, belts, brake linings, fuses, blades, seals and other service parts unless it can be proven that the item has evidence of faulty manufacture.
- c) The warranty policy will not cover failure or damage caused as a result of parts or accessories being modified without the written approval of GJ Handy & Co Ltd.
- d) The warranty policy will not cover the unit if non-genuine parts have been fitted and as a result damage has occurred to the unit.
- e) The warranty policy is non-transferable and is only applicable to the original purchaser.

Disclaimer

- a) This warranty is only a remedy for defect of products. GJ Handy & Co Ltd will never warranty in terms of the merchantability or the fitness for a particular purpose.
- b) No person is authorised to make any warranties, representations or promises, expressed or implied, on behalf of GJ Handy & Co Ltd, or to modify the terms conditions or limitation of this warranty policy in any way.
- c) Neither GJ Handy & Co Ltd nor any company affiliated with GJ Handy & Co Ltd shall be liable in any event or manner whatsoever for incidental or consequential damages or injuries, including, but not limited to, loss of crops, loss of profit, out of pocket expenses or profits, rental of substitute equipment or other commercial losses.

General

- a) Most warrantable failures show up within the first few weeks of use. These failures are usually straightforward and warranty assessment is relatively easy.
- b) Failures relating to cutter decks and belts need careful investigation, as the cause may not always be straightforward. Look for damage to blades and pulleys especially when the cutter belt or blade boss have snapped or cracked as this could be due to impact damage.
- c) Customers should always refer to the operator/instruction manual when any disputed problem arises, you will find most areas covered within the manual.

VERSION 4 – (10/16)

23/03/2017

For spares or support of your handy product,
please contact us:

Tel: 01793 333212

Email: customerservice@handydistribution.co.uk
(Mon – Fri 8.00am to 5.30pm excl. Bank Holidays)

To see our range of garden machinery & equipment visit:

www.thehandy.co.uk

Making gardening easier & affordable since 1938

Distributed by Handy Distribution, Murdock Road, Dorcan, Swindon, SN3 5HY